

SPITFIRE

AURORA



IMPORTANT - READ THIS FIRST!

Before assembling model, study sketch carefully.

Important—Apply cement to inside surfaces only. Avoid getting cement on outer surfaces of model sections. Use cement very sparingly and avoid getting cement on hands, so as not to mar or smear plastic surfaces.

Do not hurry. Work carefully and patiently. Important Note: Before proceeding to cement parts together, it is advisable to fit parts together dry (without cement) so that you may familiarize yourself with the parts and how they go together, also noting the points where cement is to be applied.

For best results assemble model exactly in the order indicated.

This kit is molded of styrene plastic—

Use only

Aurora's Fireproof Styrene Cement and Aurora's Speed-Dry Enamel. Assure yourself of a perfect model every time!

© 1959

AURORA PLASTICS CORP.

West Hempstead, L. I., N. Y.

MADE IN U. S. A.

LITHO. IN U.S.A.

THIS KIT IS MOLDED OF STYRENE PLASTIC

Use Only . . .

AURORA'S
FIREPROOF
STYRENE PLASTIC
CEMENT



TUBE 10¢

BOTTLE with BRUSH 25¢

"THE ENAMEL WITH THE SPRAYED ON LOOK"

- ONE COAT COVERS
- NO BRUSH MARKS
- DRIES IN 30 MINUTES



SPEED-DRY ENAMELS are AURORA'S REVOLUTIONARY NEW ENAMEL PAINTS developed after years of research especially for Plastic Models and other products of Wood, Metal, Glass or China.

SPITFIRE ASSEMBLY INSTRUCTIONS



Before assembling the SPITFIRE, carefully study above sketch and place all parts on work table as indicated.

IMPORTANT: — APPLY CEMENT TO INSIDE SURFACES ONLY AVOID GETTING CEMENT ON OUTER SURFACES OF PLANE SECTIONS.

In order to obtain maximum strength and neatness it is suggested that all cemented sub-assemblies be given ample time to dry before further handling.

1. Cement both parts of stand together and allow to dry.
2. Cement propeller shaft to propeller and allow to dry.
3. Cement right and left wing to fuselage by inserting wing tab into slot in fuselage section and applying cement on the inside. Set aside to dry.
4. Cement elevators to fuselage by inserting elevator tab into slot in rudder and applying cement on the inside.
5. Cement fuselage and wing sub-assemblies together by applying cement to edges of fuselage halves, being careful not to get any cement near or around propeller shaft hole — **IMPORTANT:** Place propeller and shaft assembly into proper position in fuselage before joining fuselage halves.
6. Cement cockpit canopy by applying cement to edges and press firmly into place.
7. Cement radiator (square shaped piece) to underside of right wing by applying a small drop of cement to pegs on radiator and inserting same into corresponding holes (closest to fuselage) in right wing.
8. Cement oil cooler (cigar shaped piece) to underside of left wing in holes closest to fuselage.
9. Cement bombs to underside of left and right wings using same procedure as for radiator and oil cooler.
10. Cement landing gear to underside of left and right wings by applying a small drop of cement to small peg on landing gear and inserting same into corresponding holes in wings. — **NOTE:** — Place plane in upside down position and hold or prop landing gear in proper position until cement has enough time to set or dry.
11. Cement tail wheel to underside of fuselage assembly. Use same procedure as in cementing landing gear. — **NOTE:** — Allow landing gear and tail wheel to dry thoroughly before any further handling.
12. Cement ANTENNA MAST by applying cement to broad end of mast and place into slot on top of fuselage.
13. Apply cement to tab on arm of base and place into slot on underside of fuselage and hold or prop into position until dry.
14. Cut out sections of decals to correspond with markings on plane. Read directions on back of decals before applying.

Allow to dry before further handling.





Every effort has been made to insure the completeness of this Kit—however, should any part be missing, write directly to:

AURORA PLASTICS CORP
West Hempstead, L. I., N. Y., Dept. M

(When writing please print your
NAME and ADDRESS PLAINLY)

Mail this coupon and 25c
for your New **AURORA FULL COLOR**
44 PAGE COLLECTOR'S CATALOGUE
OF HOBBY KITS

AURORA PLASTICS CORP DEPT C
44 Cherry Valley Rd., W. Hempstead, New York

Please rush me by return mail the new 44 page full-color AURORA HOBBY KIT CATALOGUE. I am enclosing 25c in stamps or coin.

NAME
(PLEASE PRINT)

ADDRESS

CITY

ZONE

STATE

CONTENTS: MERCHANDISE—Postmaster: This parcel may be opened for postal inspection. Return postage guaranteed.

Cut Along Line

**GET AURORA'S FULL COLOR CATALOGUE
FOR A COMPLETE LIST OF HOBBY KITS!**