



A-10 FOD Plug Set

Scale : 1/48

Media : Resin

Item Nr. : R48003



R1

Inlet Plug

(2 pieces)



R2

Exhaust Plug

(2 pieces)



R3

Gun Cover

(1 piece)



R4

Gun Scoop Inlet Plug

(1 piece)

Assembly Instructions

For Italeri Kit

- Paint and mask R1.
• Assemble R1 to kit part 3D.
- Assemble kit parts 3A and 4A.
• Paint engine cover interior (kit part).
• Paint and mask exhaust plug (R2).
• Assemble R2 inside the engine cover.
• Assemble kit parts 5A, 6A and 3D.

For Academy Kit

- Paint plug (R1).
• Assemble R1 kit parts D38, B3 and B9 after finishing the model.
- Do not use kit parts D25 and D31.
• Paint engine cover interior (kit part).
• Paint and mask exhaust plug (R2).
• Assemble R2 inside the engine cover.

- Do not use kit parts 1D, 2D and 21D (G)
 - Assemble 3D and 4D.
- 3.
- Paint nose gun cover (R3).
 - You can assemble R3 after finishing the build. But do not glue nose gun (kit parts 7C, 8C, 9C).
 - It is optional to use rotary gun or gun cover on display.
- 4.
- Paint and mask gun scoop inlet plug (R4).
 - Assemble R4 inside the kit part 45C.

Assemble kit parts D38, B3 and B9.

- 3.
- Cut the nose gun alignment pin inside the gun body (kit part A48) (pic.1).
 - Paint the nose gun cover (R3).
 - Assemble R3 to the gun body after finishing the model.
- 4.
- Cut the nose gun body (kit part A48) from the marked line (pic.2).
 - Paint and mask gun scoop inlet plug (R4).
 - Paint inside the kit part F2.
 - Assemble R4 inside the kit part E2.
 - Follow kit instructions for the rest of the build.

Pic.1



Pic.2



TIGER HEAD MODELS 2024



www.tigerheadmodels.com

www.tigerheaddecals.com